

Getting Started with Communicator 5 Accessible Apps: Quick Guide

This document provides instructions on how to set up and get started with the Communicator 5 Accessible Apps page sets. Additional tips are also included.


Requirements: An unlocked device with access to the Internet is required. Some of the accessible apps require an account to use. (i.e. a Facebook account, a Netflix account, a Google account, etc.) Refer to the quick guide for each individual accessible app for details.

Note for I-13 and I-16 users: You will first need to run Update Notifier. Then follow the prompts to Download and Install the Join-In Accessible Apps for Communicator 5.

Note for users with Accessible Apps on other available devices: You will first download and run the Join-In installer using the link on the license card provided you.

Find and Add Accessible Apps Page Sets in Communicator 5


- Launch Communicator 5
- On the Communicator 5 Home Page, select **Edit Home Page**




- On the Edit Home Page screen, select **Add Page Sets**




- On the All Page Sets screen, select **Text Communication**




- On the All Page Sets - Text screen, select the **Add-On Products** tab on the left. Accessible Apps page sets are listed on the right.




- Add each accessible app page set (including Join-In Options and Join-In Sign In) to Home Page
 - Select an app
 - Select **Add to Home Page**



- After all accessible apps are added, select **View**




- Now all the accessible apps are available for easy access on the Communicator 5 Home Page




Set Up Preferred Access/Selection Method for Using the Accessible Apps


- On Communicator 5 Home Page, select **Join-In Options**




- On the left toolbar, select **Join-In Options**, then select **Pageset Settings**



- Select the preferred access method, then select **Back**



- The **Accessibility Settings** provide additional options for customization. Select **Back** after adjustments



Note: The parameters set here will be active across all accessible apps, but will not affect selection of Communicator 5 buttons.

- Select **Apply Changes** or **Discard Changes**

Apply Changes will exit the Join-In Options and return to Communicator 5 Home Page directly.


Discard Changes will provide an additional confirmation screen before returning to the Communicator 5 Home Page.

Use the Accessible Apps for the First Time

- On Communicator 5 Home Page, select an accessible app image to launch it

(Note for users with Accessible Apps on other available devices: When opening an Accessible App for the first time you will be prompted to enter in your license number provided on the license card in the out of box materials)

- The left toolbar appears with buttons to open the app, log in with additional information, and exit



Select to open the app – each app will show a toolbar with buttons on the left and the content page on the right

Select this button to login the first time using each app (if required), and go to the online Training Cards page of the app

Return to Communicator 5 Home Page

**** Refer to the quick guide for each individual accessible app for more details**



Exit an Accessible App



- When finished using an accessible app and ready to return to Communicator 5 Home Page, select the **Menu** button on the left toolbar
- Select the **Exit (Communicator Home Page)** button on the left toolbar



- Two options are provided for exiting an app

 A square button with a large house icon and the text "Close and Exit" below it.	The big Close and Exit button closes the app and returns to Communicator 5 Home Page
 A square button with a small house icon and the text "Exit Only" below it.	The small Exit Only button minimizes the app and returns to Communicator 5 Home Page. Note: Use this option only if the user needs the app to stay open, for example, if the user wants the Spotify music to play on the background, or if the user wants to return to the same location in Facebook.

Additional Tips

- **Recover an Accessible App and Close Extra Windows**

If the user gets “lost” when using the app, or has no response when in the app, look for the **Utilities** button (usually on the Menu Toolbar).



Use the **Recover** button to reload / reopen the app’s home page


Use the **Close Window** button to close extra windows that are no longer needed

Use the **Window Mode** button to exit full screen mode and get access to the device desktop

- **Enable Direct Selection**

In some cases, Accessible Apps allow direct selection from the app area, for example, selection of a YouTube video, a post to view on Instagram, a contact in WhatsApp etc.

To enable direct selection, use the **Select** button. After doing that, the selectable items on the screen will be highlighted.



- **Permission**

Some accessible apps require permissions such as using the computer camera and microphone. These permissions are granted by Communicator 5 Accessible Apps automatically. For details, refer to the quick guide for each accessible app.